# Type BR Loadcenters and Circuit Breakers

## **Options and Accessories**

#### BRSF125

### **Field Installation Kits and Parts**



3BRS225



BRL200



TDI



Number of Poles	Ampere Rating	Number of 1-Inch (25.4 mm) Spaces Needed	Wire Size Range Cu/Al 60 °C or 75 °C	Ordering Quantity ①	Catalog Number
Main and S	ıb-Feed Lug Blo	ocks			
2	125	2	#8-2/0	1	BRSF125
	150	2	#8-2/0	1	BRSF150 <sup>2</sup>
	225	4	#2-300 kcmil	1	BRS225
3	150	3	#8-2/0	1	3BRSF150 <sup>2</sup>
	225	6	#2-300 kcmil	1	3BRS225
Main Lugs					
Two-pole, 200 A stud mounted (includes deadfront filler plate) #1-			#1-300 kcmil	1	BRL200
Neutral/ground lug Add-on neutral or ground lug #2/0 maximum #3/0 maximum			#2/0 maximum	1	NL20
			#3/0 maximum	1	NL30
			300 kcmil maximum	1	NL300
Filler Plates					
1-inch (25.4 mm) circuit breaker space				25	BRFP
BW main circuit breaker space (with hardware)				1	BWFP
Door lock —12–42 circuits, and 100–225 A				1	TDL
Door lock—4–8 circuits, 125 A				1	CH9FL
ANSI-61 light gray touchup paint for current loadcenters				1	SPC61
Isolated neutral assembly (computer circuits)				1	BINA
Circuit directory—adhesive backed				10	TCD
Cover screws				25	LCCS
Cover replacement latch (gray) 14-5/16 (363.5 mm) wide loadcenters only				1	BRRL
Circuit marking strip (next to breaker)				10	BRMS
Circuit identification label (preprinted breaker labels)				25	CHBL
Series rated caution label				25	SRL
Bonding strip with screw				1	BSSUSE

#### Notes

- ① Must be purchased in multiples of ordering quantities indicated.
- $^{\circ}$  #8–2/0 wire size range is 75 °C rated only.